


iPega® 多功能无线接收器产品说明书

(PG-9132)中文版

适用说明:

- 1.非常感谢您购买ipega品牌的PG-9132多功能无线接收器;
- 2.产品主要适用于适用于Switch / PC(Xinput/Dinput)/ANDROID 模式下进行游戏操作时使用;
- 3.兼容手柄 X1S、P3、P4、Wiiu、Switch_Pro;
- 4.产品支持无线及有线两种连接方式;
- 4.结构符合人体工程学,外观简洁,连接简单;
- 5.无需特殊操作一键自动配对连接, 配对后接收器LED对应显示状态;
- 6.支持自动回连功能;

功能图示:



*以上手柄均支持有线/无线两种连接方式 (WIIU手柄不支持有线连接)

LED指示模式对应表:

设备名称	模式	操作方法	LED指示	备注
Switch	标准模式	按接收器配对按键	红色LED	
安卓	安卓盒子	按接收器配对按键	白色LED	
	安卓手机(OTG转接)	按接收器配对按键	白色LED	
PC	Dinput	按接收器配对按键	红色LED	长按手柄上的SELECT加START切换
	Xinput	按接收器配对按键	蓝色LED	

设备使用说明:

配对方式及使用说明:

1. 首先使P4/Switch/X1S手柄进入配对状态, 然后将接收器插入主机内, 此时接收器LED指示灯慢闪, 处于回连模式。
2. 按下接收器的配对键, LED指示灯快闪, 进入配对模式, 等待自动配对, 配对成功后指示灯常亮。

手柄无线配对方式:

手柄	配对方法
P4	SHARE+PS(HOME)
Pro	按下同步按钮
Wiiu	按下同步按钮
X1S	开机后长按同步按钮
P3	参考说明书详细说明

手柄有线配对方式:

手柄	配对方法
P3	按下直接插入数据线即可
P4	
Pro	
X1S	
Wiiu	不支持有线连接

电性参数:

- 1.产品尺寸: L51*W23*H9.7MM mm
- 2.产品重量: 7±2g
- 3.工作电压: DC5V
- 4.工作电流: <10 mA
- 5.连接方法: BT无线传输距离: ≤8M(支持有线连接)
- 6.多彩指示灯显示, 不同模式指示灯颜色不同

备注:

1. P3手柄的配对过程是通过尾部的USB_HUB端口进行, 把P3手柄插入尾部的USB接口, 拔出后进行蓝牙配对连接, 不需要通过电脑配对。
2. 在配对过程中, 如果由于周围环境干扰影响, 造成长时间未能自动配对, 请重新拔掉接收器并且将手柄关机, 然后重新进行配对操作即可。
3. 尾部的HUB接口 也可以通过有线转换使用。

iPega®

Multi-Function Wireless Receiver


Instruction (PG-9132)

Applicable instructuons:

With this product, you can use your any X1S, P3, P4, Wiiu, Switch Pro controller to play games on any of Switch console/ PC(X-input or D-input games) or Android devices.

- 1.Thanks for purchasing iPega developed Multi-Function Wireless Receiver.
- 2.This receiver support playing games on Switch/PC/(Xinput/Dinput)/Android.
- 3.Compatible controller: X1S, PS3, PS4, Wiiu, Switch_Pro.
- 4.Support wired and wireless connect mode.
- 5.Ergonomic design and easy to connect.
- 6.Simple one key to be connected, LED indicator shows the corresponding condition.

Function Instruction:



*Both wired and wireless connection apply to PS3/PS4/XB1S controller.
(Wii U controller only support wireless connection) .

LED Indicator Mode :

Device Type	Mode	Operating Method	LED Indicate	Remark
Switch	Standard mode	Press the button of receiver	Red LED	
Android	Android box	Press the button of receiver	White LED	
	Android smart phone (OTG adapter needed)	Press the button of receiver	White LED	
PC	DINPUT	Press the button of receiver	Red LED	Press select and start button 3-5 seconds of ontroller to shift modes
	XINPUT	Press the button of receiver	Blue LED	

Instruction:

Firstly, P4/Switch/X1S controller enter into pairing mode, then insert the receiver into console, the LED light on receiver will flash slowly, means under reconnecting mode.

- 1.Press the pairing key of receiver, LED flash quickly, showing under connecting mode, the receiver will connect automatically, LED light will be on after connect.

Wireless Controller Connect Method:

Controller	Pairing Method
P4	Press share +PS(HOME)button
Pro	press Synchronous button
Wiiu	press Synchronous button
X1s	Turn on the devices, then press Synchronous key for a 3-5 seconds.
P3	Detailed information, find the below remarks

Wired Controller Connect Method:

Controller	Pairing Method
P3	Plug the cable into the USB interface of PC devices
P4	
Pro	
X1s	
Wiiu	Do not support wired connect.

Electrical Parameters:

- 1.Size:(L)51*(W)23*(H)9.7MM
- 2.Weight: 7±2g.
- 3.Working voltage: DC5V;
- 4.Working Current:<10mA
- 5.Connecting method :wireless and wired , BT transmission distance:≤8M
- 6.Multi-color indicators, different color represent different functions.

Remark:

- 1.P3 controller connect receiver is by the USB_HUSB interface, link the PS3 cable into USB port of receiver to turn on the controller, then pull out the receiver, connect with BT is ok, no need through computer connect.
- 2.During the connect process, if not connect successfully by the interference of surroundings, please reinsert the receiver and turn off the controller, reconnect again.
- 3.HUB interface also can be used by cable.