




P 4 充电座


产品说明书(PG-P4003)



产品特点:

- 1.本产品是一款适用于P4系列原装手柄的座充.
- 2.智能充电控制,充满后自动停止充电.防止过充对电池造成损伤!
- 3.带充电指示灯,在充电过程中,便于识别充电状态.
- 4.充电座电具备有短路保护功能
- 5.配备专用的充电转接头.无线连线充电.使用非常方便.
- 6.隐藏的USB电源线.在不使用时方便收纳.

产品概览:



电性参数:

输入电压: DC4.75V-5.25V 输入电流: ≤ 1200 mA
单组充电电流: $\leq 500 \times 2$ 充电时间: 6小时


产品使用说明:

- 1.将座充底部的USB线取出插入P4主机的USB端口, ”ipega” 指示灯点亮,把座充平放于主机上面 (见首页图) .也可以连接至其它5V电源的USB端口使用(电流大于1A以上).
- 2.将专用的充电转接头插入P4手柄的充电接口,然后将插好转接头的P4手柄放入充电槽1或充电槽2开始充电.
- 3.手柄充电时, 对应的充电槽指示灯闪烁, 充满后对应的指示灯常亮。
- 4.在手柄充满电后, 如果将手柄从充电槽移开,再次放入充电槽时,充电指示灯将在会短时间闪烁后恢复常亮, 表示此手柄已经充满电。

注意事项:


- 1.请不要在高温环境下充电使用!
- 2.请勿擅自拆卸进行改造, 以免发生故障和造成伤害!
- 3.避免暴晒、雨淋、受潮、受热!
- 4.不宜放置在通风不好地方充电!
- 5.请勿采用化学溶剂清洗本产品!

产品清单:



CHARGE STATION FOR P4


Product Manual(PG-P4003)



Features:

- 1.This product is suitable for PS4 series.
- 2.Intelligent charging control, automatic stop charging after full.Prevent overcharge damage to the battery.
- 3.Comes with charge indicator. In the process of charging, easy to identify the charging status.
- 4.Equipped with a dedicated charging adapter.Wireless charging for convenient use.
- 5.Hidden USB power cord. Convenient storage when not in use.

Product appearance illustration:



Product parameter:

Input voltage: DC4.75V-5.25V Input current: ≤ 1200 mA
Single charging current: $\leq 500 \times 2$ Charging time: 6 H

Product instructions:

- 1.Take out charger USB cable at the bottom and insert to the console, ipega port light.Put the charger on the flat on the host (see picture) also can be used to connect with other 5V USB port for power. (The current is greater than 1.0A)
- 2.Insert the special adapter into the controller,then put the controller into the charging slot 1 or slot 2 to start charging.
- 3.When the controller is charging, the indicator light of the corresponding charging slot flashes, and the indicator light is always on after full charge.
- 4.After the controller is fully charged, removed from the charging slot and put into the charging slot again, the charging indicator light will stays on after flicker for a short time, indicating that the controller is fully charged.

Notes:

1. Please do not charge it under high temperature environment!
2. Do not disassemble for reconstruction without permission, so as to avoid failure and damage!
3. Avoid exposure to the sun, rain, damp and heat!
4. Should not be placed in a ventilated place to charge!
5. Do not use chemical solvent to clean this product!

Included:

