

ipega®

N-Switch有线手柄


产品说明书 (PG-SW012 幻影精灵)

产品特点

- 1.本手柄适合操作N-Switch/P3/安卓及电脑(Win 7以上系统)设备上的游戏;
- 2.本手柄的功能按键——对应N-Switch_pro手柄的按键功能,并且支持TURBO连打功能;
- 3.本手柄支持有线连接进行游戏的控制;

*因官方游戏平台软件升级或源代码变更等不可抗拒的因素造成部分游戏无法与本产品连接操作, 我公司不负任何责任。对此我公司保留最终解释权。

功能按键图示



产品使用说明

Switch主机连接

- ① 在连接之前,请确认N-Switch主机的系统设置中,‘Pro手柄的有线连接’处于开启状态;
- ② 手柄通过USB数据线与Switch底座连接上,手柄的相应指示灯常亮,
- ③ 拔掉USB线,手柄断开连接!

安卓设备连接(安卓标准HID模式)

- ① 长按“+ (START)”键,同时将手柄数据线与安卓设备连接,手柄LED1灯常亮;
- ② 拔掉USB线,手柄断开连接!

P3主机连接

- ① 长按“+ (START)”键,同时将手柄数据线与P3设备连接,手柄LED自动分配并常亮;
- ② 拔掉USB线,手柄断开连接

PC 主机连接

- ① 长按“+ (START)”键,同时将手柄数据线与PC设备连接,手柄LED2常亮;
- ② PC设备支持模式切换:
连接后默认为P3(D-INPUT)模式,长按HOME5秒切换为360(X-INPUT)模式;
- ③ 拔掉USB线,手柄断开连接

TURBO功能

- ① 动作键包括(A/B/X/Y/L/ZL/R/ZR) 8个按键,均可手动设置TURBO功能;
- ② 设置方法 (Switch主机):
长按动作键,同时再轻按TURBO 键,TURBO功能开启;长按动作键,同时轻按TURBO键关闭;
- ③ 设置方法 (P3/安卓/PC):
长按动作键,同时再轻按TURBO 键,TURBO功能开启;长按动作键,同时轻按“O”键关闭;
- ④ 产品断开连接后,之前设置TURBO功能自动清除,若启用TURBO功能时,必须重新设置;

产品技术参数

产品重量:240±5g
工作电压:DC5V
工作电流:<30mA

注意事项:

- 1.请不要把本产品放在潮湿或高温地方存储;
- 2.不要敲击、摔打、棒打、刺穿、或试图去分解本产品,以免对产品造成不必要的损害;
- 3.非专业人员请勿拆卸本产品,否则不在售后保修服务内;

产品清单:



游戏手柄 x1



说明书 x1



Wired Controller for N-Switch


User Manual (PG-SW012 Phantom elf)

Product features:

- 1.Compatible with N-Switch/P3/Android/PC(Win 7)
- 2.Function keys are match with N-Switch_Pro,and support TURBO function
- 3.Support play game with wire connect

*Due to the official game platform software upgrade or source code changes and other not resist factors caused of some games can not be played or connected with our gamepad. Our company has no responsibility, we reserves the right of final interpretation for this.

Illustration for button function:



Basic Operation:

Connect with Switch console

- ① please open "Pro wire connect" on N-Switch system before connect
- ② LED light while controller connect with Switch by USB
- ③ take out the USB,disconnect

Connect with Android device(Android HID pattern)

- ① long press "+" (START)", same time connect controller with Android device,LED 1 light on
- ② take out the USB,disconnect

Connect with P3 console:

- ① long press "+" (START)", same time connect controller with P3 device,LED light on and automatic connection
- ② take out the USB,disconnect

Connect with PC:

- ① long press "+" (START)", same time connect controller with PC,LED 2 light on
- ② PC support choose pattern:after connect,default pattern is P3(D-INPUT),long press HOME 5 seconds can be change to 360(X-INPUT) pattern
- ③ take out the USB,disconnect

TURBO function:

- ① action button A/B/X/Y/L/ZL/R/ZR can be seted to TURBO function
- ② setting method(Switch console):long press action button,same time press TURBO to enable;
long press action button,same time press TURBO to disable
- ③ setting method(P3/Android/PC):long press action button,same time press "O"to enable;
long press action button,same time press TURBO to disable
- ④ TURBO function setting will be deleted after disconnect,need to reset next time

Electrical parameters:

product weight: 240±5g
working voltage: DC5V
working current:<30mA

Notes:

- 1.Please do not store this product in wet or high-temperature areas.
- 2.Don't knap,beat, drub, pierce, or try to decompose this product, to avoid unnecessary damage to the product.
- 3.Non professional personnel should not disassemble the product,otherwise it will not be covered in the after-sales warranty service.

Accessories List:



Game Controller x1



User manual x1