


# 无线麦克风

产品说明书(PG-9207)



## 产品特点:

1.本产品主要用于P5/P4/N-S/Wii U游戏主机卡拉OK使用; 2.产品配备无线接收器。无线话筒、即插即用、非常方便; 3.产品精巧简洁、操作简单;

## 电性参数:

工作电压: DC 2.3-3V 灵敏度: -71dB 传输距离: ≤15M 指向性: 单一指向性

工作电流: ≤120mA 频率范围: 50HZ-10KHZ 输出方式: 动圈式 输出阻抗: 3.3K

## 产品说明:



## 使用说明:

P5/P4主机:

1.打开游戏主机,进入设置页面的话筒调节项。 2.把产品无线接收器插入已开机的游戏主机USB2.0母座。 3. 打开无线话筒开关,无线接收器上的蓝灯亮(自动连接 成功)即可使用。

N.S主机:

1.打开游戏主机,把无线接收器插入 N.S游戏主机USB2.0 母座,打开无线话筒开关,自动连接无线接收器。 2.进入相应游戏 (例: joysound)。

3.载入测试项匹配成功即可使用。

电源指示:

电量正常, 开机亮绿灯,

低电量时,亮橙灯,请及时更换电池。







麦克风 x1 无线接收器 x1 说明书 x1



## **WIRELESS MICROPHONE**

User Manual(PG-9207)



## FEATURES:

- 1. The product is mainly applicable to P5/ P4/ N-S/ Wii U console for singing karaoke.
- 2. Equipped with wireless receiver, wireless microphone, plug and play, easy to use.
- 3. Unique design and simple operation.

## Electrical Parameters:

Working voltage: DC 2.3-3V Working current: ≤120mA

Sensitivity: -71dB

Frequency range: 50HZ-10KHZ Transmission distance: ≤15M Output mode: Moving-coil Directivity: Uni-diectivity Output Impedance: 3.3K

### Illustration:



## How to use:

P5/P4 console

- 1. Power on the game console, enter the microphone adjustment options on the setting interface.
- 2. Insert the wireless receiver into the USB port of the game
- 3. Turn on the microphone, the receiver's blue light is on after the automatic connection is successful.

N-S Console-

- 1. Power on the NS console. insert the wireless receiver into the USB port of the console, turn on the micorphone, it will connect with the wireless receiver automatically.
- 2. Enter the games (e.g. Joysound).
- 3. Load test item, you can use it after matches successfully. Power indicator:

Normal: The indicator is green when turn on the mic. Low battery: the indicator is orange when turn on the mic, please replace the battery in time.

#### Include:







Microphone x1

Wilress receiver x1

User Manual x1