




派鲨鱼

Multi-functional Charging Stand

Product manual (PG-XBX028S)

Product Overview:



Product Description :


1. This product is suitable for the XBX console which is able to reduce the heat and charge the original controller (XBX original battery).
2. Equipped with a top-mounted powerful cooling fan, it can be controlled automatically or manually to adjust the fan speed. It provides excellent cooling performance and comes with LED lighting effects.
3. Equipped with one touch button for fan speed control and one touch button for light mode selection.
4. Equipped one headset stand to place the headset.
5. With two card slots to store the storage expansion card.
6. Game disc storage, maximum for 6 game disc.
7. RGB colorful lighting effects with a total of 11 lighting modes.
8. Compatible with the original XBX wraps for added convenience and protection.

Specifications:

Input: DC 5V/2.3A
Output: DC 5V/2A

Single controller charging current: ≤500mA
Charging Hours: ~3.5 hours

Product instructions:




1. Follow the steps shown in the diagram to assemble and connect the multifunctional charging dock and cooling fan to the console.
 2. Turn the XBX console on, the controller charging indicator A, indicator B and cooling fan status indicator light up green, controller charger into standby mode and RGB colorful lights work in the mode before the last shutdown.
 3. Align the original XBX controller with the Type-C connector in controller charging port A or controller charging port B on the charging dock. The corresponding charging indicator light will turn red, indicating that the controller is charging. When the controller is fully charged, the corresponding charging indicator light will turn green.
 4. After assembly, power on the device. The fan will enter the default automatic mode with the AUTO indicator light on. After 5 seconds of running, the temperature sensor will automatically detect the temperature of the device and intelligently determine whether the fan should continue working and adjust the fan speed accordingly.
- The "Fan Mode Switch" button can control the fan in five different modes: Automatic mode, Low-speed mode, Medium-speed mode, High-speed mode, and Stop mode. Press the button to switch between five modes.

Attention!

- ∞ Level 1
- ⊗ Level 2
- ⊗ Level 3 (Best dissipation effect, but it may noisy)

- Press one time: Turn on and go to level 1
Press two times: Level 2
Press three times: Level 3
Press four times: Turn off
Press five times: Auto mode





5. Light Switch Button: Pressing the light effect switch button allows you to cycle through the 11 lighting effects:

1. Rainbow Breath Flow
2. Rainbow Color Jogging
3. Rainbow Breath Gradient
4. Single Color Breath Gradient
5. Multi-color Overall Jumping
6. Blue
7. Aqua Blue
8. Green
9. Yellow
10. Red
11. Purple


6. Long-press the light mode switch button for 3 seconds to save the current light mode and turn off the lights. Press the light mode switch button again to enter the saved light mode. The current light mode is automatically saved when the device is powered off, and the device will enter the last saved light mode upon the next power-on.

7. Equipped with two USB ports, one with 2.0 data functionality, and the other supports low-current charging only.




Note:

- 1.The charging function only support the XBS/XBX original battery pack, please do not charge other controller and battery pack.



2. When is powered on, there is voltage inside the Type-C connector used for controller charging. Please avoid bending the Type-C connector and prevent water, metal debris, or other foreign objects from coming into contact with the Type-C connector.
3. When the controller is fully charged or close to full charge and placed on this product for charging, the charging indicator light will not change and will continue to show a green light.

Product List:




派鲨鱼

XBX多功能机甲座充

产品说明书 (PG-XBX028S)

产品外观图示:



适用说明:


- 1.本产品适用于XBX主机散热及原装手柄（手柄内装XBX原装充电电池）充电使用。
- 2.配备一个顶置式强力低噪散热风扇，可自动或手动调节风速。具有出色的散热性能与发光灯效。
- 3.配备1个风扇档位触摸按键与1个灯光模式触摸按键。
- 4.配备一个耳机支架，方便收纳耳机。
- 5.具备两个存储扩展卡槽位，方便收纳存储扩展卡。
- 6.配备游戏碟架，可放置6张游戏光盘。
- 7.带RGB炫彩灯效，共有11种灯光效果。
- 8.兼容XBX原装保护皮套使用。

电性参数:


输入: DC 5V/2.3A
单个手柄充电电流: ≤500mA

输出: DC 5V/2A
充电时间: 约3.5小时

设备使用说明:



- 1、按上图操作方法将多功能座充及顶置风扇与主机装配连接；
- 2、将XBX主机开机，多功能座充的手柄充电指示灯A与指示灯B及风扇档位灯亮绿灯，座充进入待机状态，RGB炫彩灯工作在上次关机前的模式；
- 3、将XBX原装手柄对准充电槽中的TYPE-C插头插入手柄充电槽A或充电槽B，对应的充电指示灯将亮红灯，表示手柄正在充电，当手柄充满电时，对应的充电指示灯将亮绿灯；
- 4、顶置风扇与底座连接好后开机，风扇默认进入自动档模式，AUTO指示灯亮，风扇工作5秒后，温度感应器将自动识别主机温度，智能判断风扇是否继续工作并自动调节风速。通过“风扇模式切换键”可控制风扇在：自动模式；低速模式；中速模式；高速模式；停止；五种模式之间依次切换。当顶置风扇工作时，风扇中间4个幻彩LED会点亮并发出幻彩灯效。



请注意！

- ∞ 静音
- ⊗ 中档
- ⊗ 强力（此档散热效果最好,但可能会产生噪音）


自动模式下，按一下进入手动模式低速档，再按一下切换至中速档，再按一下切换至高速档，再按一下关机，再按一下进入自动模式，依此循环.....

5. 按下灯光模式触摸切换键可以在以下11种灯光效果中依次切换

- 1: 七彩呼吸流水
- 2: 七彩变色慢跑
- 3: 七彩呼吸渐变
- 4: 单色整体呼吸渐变
- 5: 多色整体跳变
- 6: 蓝色
- 7: 水蓝色
- 8: 绿色
- 9: 黄色
- 10: 红色
- 11: 紫色


- 6、长按灯光模式切换键3秒，保存当前灯光模式并熄灯，再次按一下灯光模式切换键，进入已保存的灯光模式，关机断电时自动保存当前灯光模式，再次开机时进入最近一次断电前的灯光模式；

- 7、共配备两个USB接口，1个带2.0数据功能；另1个仅支持小电流充电功能。



产品注意事项:

- 1.本产品手柄充电功能仅适用于XBS/XBX原装手柄与原装电池组，请勿为其他非原装手柄和电池组充电。



- 2.在本产品通电工作时，手柄充电TYPE-C头内部有电压，请勿弯折TYPE-C头，避免将水、金属碎屑等接触TYPE-C头。

- 3.当手柄在满电或接近满电状态时，将手柄放在本产品上充电时，充电指示灯将无变化，仍显示绿灯。

产品清单:

